

RADOPT 2023

29th and 30th, November 2023
TOULOUSE, France

Regeneration of Phosphosilicate Optical Fiber Dosimeters operating in the Visible Domain

M. Roche, A. Morana, E. Marin, N. Balcon, J. Mekki, A. Boukenter, Y. Ouerdane, G. Mélin, T. Robin and S. Girard

Context – Long term degradation of components and systems in radiation rich environment is a major concern.

❑ Optical fibers are part of numerous systems in harsh environment (communication, diagnostics or sensors).

➤ The main risk for these applications is the radiation induced attenuation (RIA).

➤ Numerous studies were dedicated to improve radiation toleration of optical fiber-based system (S. Girard et al., J. Opt 2018)

➤ Hardly to manipulate or replace in such environment.

❑ Space dosimetry using optical fibers has produced excellent results

We evaluate the capability to retrieve the pre-irradiation performances of a P-doped Optical Fiber.




Context – RIA kinetics is explained by the competition between the generation and the recombination of absorbing point defects.

❑ Power and Wavelength of the injected light affects:

- The generation efficiency of defects
- The recombination efficiency of defects

} Photobleaching can be define as the potential recombination of a certain amount of radiation induced defects.

The efficiency of the process depends on the composition, length and geometrical properties of the optical fiber, optical power, wavelength...




- Phosphorus doped optical fibers:

It was proven that the photobleaching was efficient with the P1 defect (main responsible of the 1550 nm RIA)

(G. Li Vecchi *et al.*, Opt. Lett. 2020)

Is it possible to photobleach the various form of POHC defects, which are the major responsible color centers of the RIA in the visible domain ?

Context – Visible domain present interesting characteristics for dosimetry.




- Operation in the visible domain allows reaching coefficients significantly larger than in the infrared.
- ...but at the expense of reduced insensitivity to various environmental factors such as dose rate.
- ... can reach the RIA saturation quicker than IR dosimeter.
- Need to reset.

Tools - We measured *in situ* the RIA kinetics during and after irradiation then after photobleaching process varying the **Wavelength of the laser**.

- Phosphorus doped multimode optical fiber (from exail)
- 100 kV X-Ray irradiation up to **5 Gy** (The fibers are only sensitive to Total Ionizing Dose (TID)) (S. Girard et al., J. Optics, 2018)
- **Length of the Optical fiber = 5 m**
- Dose rate = 10 mGy/s
- **Optical power = 4 mW**
- **Room temperature**

1 Gy = 100 rad


Experimental Setup



➤ Tested Photobleaching Wavelengths:


1550 nm **1060 nm** **660 nm** **514 nm** **403 nm**

Results– 403 nm is the most efficient photobleaching wavelength



- After 2 hours of photobleaching
- NIR wavelengths are inefficient for photobleaching.
- Only the higher energy photons can photobleach the radiation induced losses from 1.8 eV to 2.8 eV.
- 660 nm and 514 nm lasers have only an impact on the RIA at lower wavelengths.
- The RIA caused by the Gaussian absorption band of s-POHC centered at 2.28 eV remains mostly unaffected by this 4 mW laser injection.


Results– 403 nm is the most efficient photobleaching wavelength



- After 2 hours of photobleaching
- The closer the ratio is to **100%**, the more efficient was the photobleaching at the reported wavelength.
- The 403 nm PB efficiency : we recovered at least 80 % of the pre-irradiation transmission capacities over the visible spectrum.
- The 403 nm laser demonstrates a particular efficiency: four and eight times better than 514 nm PB at 2.28 eV and 2.1 eV respectively.
- Focus on 403 nm photobleaching results



Results– With different photobleaching timing, we investigate Time efficiency.

$\lambda = 640 \text{ nm}$




- Different timings of photobleaching :
1 min 5 min 10 min 30 min 60 min 60 min
- Room temperature recovery is noticeable.
- **By increasing the PB treatment duration, we recover more of the transmission capability.**

Results— The PB is more effective during the **first minutes** than in the long term.




➤ **5 min laser photobleaching** allows **recovering 50%** of the transmission performance regarding on the remaining RIA compared to the **80% after 1 min laser at 450 nm**.

Results– Another observation : the surprising fast and limited RIA regrowth after the PB action.



- After the short PB period, the RIA level slightly increases.
 - Radiation induced defects absorbing in the visible are again generated, but without irradiation.
- From a practical point of view, the RIA level has to be considered after few minutes.

Results– Re-use of the dosimeter, does the RIA kinetic remain the same ?



- We irradiate the same sample three times and photobleached it 2 times, during 3 hours.
- At 640 nm, 514 nm and 450 nm: The fiber response remains the same
 - **The reset does not change the dosimeter response.**
- From a practical dosimeter point of view, the dosimeter calibration remains unchanged after a full photobleaching session.

Conclusion

- ❑ Regeneration of a phosphorus doped optical fiber dosimetry operating in the visible domain :

5 Tested photobleaching wavelengths : 1550 nm 1060 nm 660 nm 514 nm 403 nm

- Limited photobleaching effects on RIA with NIR wavelengths.
- 403 nm is the most efficient.

Different photobleaching timing were investigated

- By increasing the PB treatment duration, we recover more of the transmission capability.
- The first minute of PB is the most productive.
 - Imagine quick time of recovery for dosimetry system.

Untouched dosimetry characteristics

- The dosimeter calibration remains unchanged after a full photobleaching session.

Photobleaching optimization


- Optimizing the PB configuration (power, length, duration) should allow to recover the transmission performances in a shorter time.



Thank you for your attention!

Any questions?

Results– Generalized results of the 403 nm Photobleaching over the Visible spectra



- After the 403 nm PB treatment, the remaining RIA consists in a Gaussian-like absorption centered at 2.3 eV (540 nm)
 - seem to be associated to s-POHC defects.
- 1 min of 403 nm laser PB allows reducing by a factor 2 the losses at 640 nm and 514 nm.
- 85% of transmission performance recovery for the 450 nm RIA.